

## Installation instruction of “ISO” horizontal aluminium blinds



1. Remove the side covers from the blind.



2. If necessary, install the spacers so that the slats can move freely without touching the glass.



3. To determine the fastening points, place the cornice horizontally between the side beads of the window and mark the place for screwing.



4. Screw the blind mechanism through the mounting holes.



5. Mark the distance on the bottom bead of the window with a pencil to attach the string holder. The string must be at right angles.



6. Drill hole for attaching the holder.



7. Insert the string holder in the drilled hole.



8. Stretch the string up and lock it with the blind covers. Cut off the excess part of the string.



9. Put the top covers on the mechanism.



10. Screw the chain holder to the window frame at the desired height. Attach the control chain.